



Scan the QR code to get multilingual user manual.




## STONE M3 TWS EARBUDS USER MANUAL



### Packing list




Charging Case  
x1




Earbuds  
(with size M caps)  
x2



Earbuds Caps  
(size L & S)  
x4



Lanyard  
x1



Charging Cable  
x1




User Manual  
x1




### Specifications

Product model: STONE M3      Play time: about 5 hours  
Wireless Version: 5.3      (60% of the volume)  
Distance: 10M      Stand time: about 180 hours  
Speaker Impedance:  $32\Omega \pm 10\%$       Charging time: about 1.5 hours  
Frequency: 20Hz-20KHz      Charge interface: Type-C  
Speaker receiving sensitivity: 99 $\pm$ 3dB      Battery capacity:  
300mAh for charging case



LED indicator  
MFB  
Touch panel



Battery  
Indicator light  
Charging port



### Please read the instructions before use

- Before using the earphones, please read the manual carefully and keep it for future reference.
- Please arrange using time properly as your hearing may be damaged by using the device for a long time.
- The earphones need to be fully charged prior to first-time use.
- If the earphones is left unused for over two weeks, please recharge it periodically.
- Please use the chargers made by qualified manufacturer.
- Never disassemble or modify your earphones for any reason to avoid any damages and danger.
- Do not store the earphones in extreme temperatures (under 0°C to 45°C).
- Avoid using the indicator close to the eyes of children or animals. Do not use this earphones during a thunder storm to avoid irregular function and increased risk of electric shock.
- Do not use harsh chemicals or strong detergents to clean the earphones.
- Keep the earphones dry.




### Problem handling

- Can be connected but there is no sound:  
Click the right earbuds to increase the volume.
- One of earbuds cannot be charge:  
Clean the charging contact of the earbuds and the charging case.
- One of the earbuds cannot be connected:  
Reset the earbuds.
- If the earbuds cannot be charged, please activate the warranty and contact us for after-sales service.



Please clean the charging contacts of the earbuds and charging case frequently to avoid charging failures.


## Method of operation



Power On

1. Take out the earbuds (Earbuds auto power on).

2. After open the phone Bluetooth, Click the earbuds name to pairing.



## Operation



Play /Pause



Answer



Voice Assistant




Switch Song



Reject Call



Power on/off



Adjust Volume



Hang up

×1: Click Once  
×2: Click 2 times  
×3: Click 3 times  
2s: Press and hold for 2 seconds

## Reset

If earbuds has any connection or function problems, please reset the earbuds.

1.Disconnect the earbuds from the phone.

2.Perform a 4-tap sequence on the L/R earphones, and power off after hearing the prompt.

3.After placing the earphones into the charging case, take them out again, and wait for the earphones to auto-pair.

This manual is for reference only, the actual product may vary. Please refer to the actual product.

## Warranty card

Customer information		Seller information	
Name		Name	
Add.		Add.	
E-mail		Purchase Date	
P.C.		Product model	
Tel		Invoice number	
Date	Malfunction		Process result